



Presa

## Description



### Armrest adjustment

Allow user to adjust the armrests to desirable position.



### Armrest 4D adjustment

Grasp the armrests and adjust up-or-down, forward backward or desired angle.



### Seat depth adjustment

To move forward or backward, remain seated, press the lever up and slide.



### Tilt limiter

Push the lever in / pull out the lever to lock / unlock the tilting mechanism